

15-Language Global Translator

User's Guide www.franklin.com

Please read the following safety warnings and precautions before using your device. Note: If this device is to be used by young children, this User's Guide should be read to them by an adult and their use of the device should be monitored. Failure to do so may cause injury.

1. Getting Started

1.1 Using for the First Time

Your device is powered by one CR-2032, 3-volt battery. Before using the device, gently pull the battery insulation tab to remove it. Use a paper clip to gently press the RESET button on the back of the device. See "Resetting Your Device" for details. Warning! Pressing the RESET button with more than light pressure may permanently disable the device.

1.2 Replacing the Battery

Replace the battery when you see the low battery indicator. Warning! If the battery wears out completely, or if you take more than a few seconds while changing the battery, any user-entered information will be erased. You should always keep written copies of your important information. Follow these instructions to install or replace the battery.

- Turn the unit off and then turn it over.
- Gently push the tab on the battery cover and pull the cover off.

3. Use a paper clip, if necessary, to remove the old battery.

4. Install the new battery positive side facing up in place of the old battery.

• Note: Do not remove the foam protector from the other battery slot or attempt to install a battery there. Your device only functions with the battery where it was pre-installed.

5. Replace the battery cover.

Battery Precautions

- CAUTION: Risk of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the instructions.
- Different types of batteries or new and used batteries should not be mixed.
- Non-rechargeable batteries are not to be re-charged. Never recharge batteries that come with the device.
- Rechargeable batteries are to be removed from the device before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type are recommended to be used.
- The supply terminals are not to be short-circuited.
- Do not expose batteries to direct heat or try to take batteries apart. Follow the battery manufacturer's instructions for battery use.
- Always remove a weak or dead battery from the device.
- To avoid damage caused by leakage of the battery fluid, replace the battery or batteries once every two years regardless of how much the device has been used during that time.
- Should a battery leak, the device may become damaged. Clean the battery compartment immediately, avoiding contact with your skin.
- Keep batteries out of reach of small children. If swallowed, consult a physician immediately.

1.3 Key Guide

Function Keys

- | | |
|-----|--|
| [] | Turns the unit on or off. |
| [] | Goes to the translator entry screen. |
| [] | Goes to the Phrases menu. |
| [] | Selects the source language for translation. |
| [] | Selects the target language for translation. |
| [] | Selects the phone book, calculator or converter. |
| [] | Toggles between home and world time. |
| [] | Goes to the Games menu. |
| [] | Goes to the Settings menu. |
| [] | Shifts to type capital letters. |
| [] | Displays help messages. |

